
REPAIR PARTS FOR 48" SPIKE AERATOR MODEL 45-0406



REPAIR PARTS FOR 48" SPIKE AERATOR MODEL 45-0406

| Ref. No. | Part No. | Qty. | Description | Ref. No. | Part No. | Qty. | Description |
|-------------|-------------|------------------------------------|--|-------------|-------------|--|--|
| 1 | | 1 1 2 2 1 1 1 1 2 3 5 2 2 1 8 8 40 | 48 in. Tray Tongue End Plate Lift Stop Bracket Hitch Bracket 48 in. Shaft Washer Wheel Bracket Assembly Middle Brace Lift Bracket Assembly Lift Handle Brace Tube Hex Bolt, 1/2-13 x 5-1/2 in. Long Hex Nut, 1/2-13 Nylock Washer, 0.5312 in. Hex Nut,1/2-13 Spacer, 1.00 in. Long Spacer, 2.38 in. Long Hex Bolt, 5/16-18 x 3/4 in. Long Washer, 5/16 in. Hex Nut, 5/16-18 Nylock | I | | 9 2 4 10 1 2 6 1 1 4 8 32 32 4 2 1 2 1 | Hex Nut, 3/8-16 Nylock Cotter Pin, 9/64 x 1-1/2 in. Long Hex Bolt, 1/4-20 x 3/4 in. Long Hex Nut, 1/4-20 Nylock Hex Bolt, 3/8-16 x 2 in. Long Washer, 3/8 in. Flat Head Hitch Pin, 3/8 in. x 3 in. Hair Cotter Pin, 3/32 x 1.80 in. Hex Bolt, 1/4-20 x 1-3/4 in. Long Clevis Pin Hex Bolt, 1/2-13 x 1-1/4 in. Long Double Spool Assembly Bearing, Flange Aerator Point Carriage Bolt, 5/16-18 x 3/4 in. Lock Washer, 5/16 in. Grease Fitting, 1/4 in. Wheel/Tire Assy., 4.10/3.5-4 Handle Grip Spacer, 1.75 in. Long Owners Manual |
| 22 | 43001 | 8 | Hex Bolt, 3/8-16 x 1 in. Long | | 70221 | ' | Owners manual |

